


WE REALLY DO CARE!


We make each toy with tender loving care. If there is a problem with your toy, as you receive it, please let us know. Simply describe the problem and mail that description along with

your name and address to: KENNER PRODUCTS Consumer Relations Dept. 1014 Vine St. Cincinnati, Ohio 45202. For added play, the SPEEDER BIKE vehicle will "explode" apart by pressing "knapsack" button on rear of toy.


LANDING AND TAKING OFF


Speed flaps are in the down position as long as your SPEEDER BIKE vehicle is on the ground. When it "takes off" the landing pads automatically drop and the "speed flaps" are raised to expose engines. (If one of the "speed flaps" should come off during play, put it back into place as shown).





066302700





Attach upper body shell to main body assembly by inserting hook (a) as shown and press upper body shell down firmly until it snaps into place on the main body assembly (B).

Slide front extension into place and it will snap into position

If the upper fin becomes separated from the front extension, simply push it back together as shown.

Put your BIKER SCOUT™ Action Figure onto the seat by sliding his legs under the spring-loaded T-Bar. It will hold him in place by fitting over his thighs. His hands can reach the "hand grips".

